


## Multifuser Wood 64 | wall

Page 1 of 1 |



### Required Apparatus:


- Multifuser Wood 64 (Panel)
- Vicoustic Flexi Glue
- 1 x Glue Gun
- 16 x Screws
- Drill
- Bubble level tool
- 4x wooden hinges
- 16 x Bushings
- Pencil

### Installation Instructions:

Wall surfaces should be examined prior to installation, ensuring they are clean, smooth, and dry. If you have unpainted gypsum board surfaces, these should be primed with a drywall primer (or another material manufactured especially for the purpose), to equalize the absorption between the gypsum board face paper, joint compound, and skin coating materials. You should then apply the paint, and allow air circulation in order to dry the paint within the time frame specified by the paint manufacturer. Please ensure the paint is dry before installing the acoustic panel. Make sure the room has all the conditions necessary to receive the acoustic panels. After you apply the glue on the back of each acoustic panel, please ensure you hold the acoustic panel on the wall the required time (mentioned below), and ensure it stays fixed in place.


### STEP 1

Drill 16 holes on the wall and install 16 bushings. We recommend doing a prior marking of the screw locations, using our scheme with a bubble level help.




### STEP 2

Screw the 4 wooden hinges to the wall.




### STEP 3

Apply the Vicoustic's Glue to the back of the acoustic panel.



### STEP 4

Hook the acoustic panel on to the wooden hinge on the wall.



### STEP 5

Hold for 1 minute and ensure it stays fixed in place.

